



# USING MASS FLUX ANALYSIS TO IMPROVE SITE CHARACTERIZATION AND REMEDY SELECTION


Patrick Curry, CPG - Arcadis, Novi, Michigan Joseph Quinnan, PE, PG - Arcadis, Novi, Michigan Nick Welty, PG - Arcadis, Novi, Michigan

April 20, 2016

#### ARCADIS Design & Consultancy for natural and built assets Design & Consultancy for natural and built assets

# **Outline**

- Introduction to Mass Flux
   & Mass Discharge
- Stratigraphic Flux
  - Depositional Environment
  - Facies Permeability
- Hydraulic Conductivity Profiling Tools
- Case Studies



## Why Does Flux Matter?




# Contaminant distribution is only half of the story

 Need to distinguish mass in high permeability and low permeability zones to understand mass transport

# Mass Flux describes the concentration of contaminant movement

- Understand risk
- Evaluation of focused remedy





## Mass Flux and Mass Discharge

#### Mass Flux - the mass flow across a unit area

J = K i C (mass/time/area)

K = Hydraulic Conductivity (i.e. permeability)


i = Hydraulic Gradient

C = Concentration (in groundwater)

#### Mass Discharge integrated mass flux

 $M_d = \int_A J dA$  (mass/time)

- J = Mass Flux
- A = Total area



Mass Discharge ( $M_d$ )

Adapted from ITRC, 2010


## **Relative Mass Flux**



We can drop the gradient term, as K varies >> i



#### **Relative Mass Flux**






6

# Where the Groundwater Flows...

Most soil types are not aquifer material

 The aquifer matrix is laid down in high-energy environments

 High-energy environments are heterogeneous and anisotropic




© Arcadis 2015



Link mass flux analysis with classical geological interpretation to describe the 3-D aquifer architecture

- Focus evaluation on zones that matter
- Helps prioritize remediation efforts

#### **Meandering Channel**







# **Facies and Permeability**



# Detailed soil descriptions key:

- High permeability, coarse grained at base
- Decreasing permeability & grain size toward top
- 5+ orders of magnitude variability in K

Hydraulic Conductivity (cm/s)

<10<sup>-5</sup> Storage

Slow Advection

~10-3

~10-4

**Transport** 


~10-2

>10<sup>-1</sup>

<10<sup>-5</sup>

Fast Transport

Storage




# Basis for Interpolating Borings



Accretion from right to left:

- Depositional environment allows for better interpretation between borings
- Provides first basis for the interpretation of stratigraphic flux – transport vs storage





# Measurement of Mass Flux and Mass Discharge

Contaminant -Passive Flux Meters Mass Tracers Well Capture Transect Methods Nichols and Roth, 2004


# Traditional Transect Method


- 1. Transect perpendicular to plume
- 2. At each sample interval collect:
  - Groundwater analytical (C)
  - Hydraulic Conductivity (K)
- 3. Calculate J and M<sub>d</sub>


Time consuming and of limited resolution:

- Conductivity measurements typically bias low
- averaged across several feet









 $Md = \int_A J dA$ 

Nichols and Roth, 2004

# **K Profiling Tools**

# Geoprobe Hydraulic Profiling Tool (HPT):

 Inject 200-300 ml/min of water and records aquifer response


# Waterloo Advanced Profiling System:

 Similar approach as HPT, can collect groundwater samples in same push

#### **CPT Pore Pressure:**

 Ambient pressure response to cone advancement






# **K Profiling Tools**

Map facies and permeability with continuous relative K profile:

- HPT Est. K (Q/P)
- Waterloo Profiler Index of K




# The K Challenge


Hydraulic profiling tools easily separate:

 Transport zones from storage zones

Estimate absolute K in relatively small window of conductivity:

- ~ 10<sup>-4</sup> to 10<sup>-2</sup> cm/s
- Slow advection to low-end of transport range





Permeability (cm/s)

# **Groundwater Concentration**

#### **Transport Zones**

Vertical aquifer profiling

- Direct Push: screen point sampler
- Sonic: temporary well / packer assembly
  - Drilling with water requires dye
- Traditional (Augers): temporary wells, Simulprobe
- Waterloo Profiler, HPT-GW

#### **Storage Zones**

Saturated soil sampling

 Estimate groundwater concentration based on partitioning or leaching method










# Case Study: Flux Based Optimization of P&T System

# Scope



# Optimize capture of existing P&T system

- Stratigraphic flux transect around northwest corner of property
- HPT for relative K
- Vertical aquifer profiling for concentration




## **Geologic Setting**



Sea Island Section of Atlantic Coastal Province:

- barrier islands
- salt marsh deposits
- streams




#### PARCADIS Design & Consultancy for natural and built assets

# **Geologic Setting**

#### Cypresshead Formation:

- Upper "massively bedded" fine sand
- Lower- greater clay and silt fraction




# **Hydraulic Profiling**



**Geoprobe® HPT Tool** 







### **Relative K**



Flow (Q) / Pressure (P) = Est. K(Q/P)




 Q/P corrected based on empirical relationship with slug test data developed by Geoprobe




## **Stratigraphic Correlation**






## Naphthalene (ppb)











<1,000

© Arcadis 2015










<1.000



# Case Study: 3D Stratigraphic Flux


# **Multliple Transects**






Stratigraphic Flux Model





# **Summary**






Hydrofacies mapping & hydraulic profiling provide key advantages:

- Relative K can be displayed graphically, or interpreted in 3D model
- Allow for stratigraphic correlation and mapping of permeable zones
- Methods readily distinguish transport zones from storage zones - "stratigraphic flux"



# **Summary**

# Stratigraphic Flux: Focus the evaluation on zones that transport mass



#### Focus on the Mass that Matters



# Thank you!



Patrick.Curry@arcadis.com

Joseph.Quinnan@arcadis.com

Nick.Welty@arcadis.com

